

- Transfers parts between two flip pallets and a W-12SA SMD Crystal Disc or a W-12SA SMD Oscillator Disc
- Can be configured to unload only, load only, or unload and load W-12SA Discs
- Simple flip pallets transfer SMD parts in and out of auto-mount pallets
- Failures can be binned into 1 of 4 bins using USB disc file from W-12SA



### TYPICAL THROUGHPUT

<b>Load Only:</b>	1.4 sec per part
<b>Unload Only:</b>	1.4 sec per part
<b>Unload and Load:</b>	2.8 sec to unload one part and load one part